

ASPEN 4 Installation Manual 03/11/25

INSTALLATION MANUAL i3CONNECT ASPEN 4

INDEX

GENERAL SAFETY PRECAUTIONS

UNBOXING

HANDLING

PRODUCT IDENTIFICATION

PREPARING INSTALLATION

FIRST TIME POWER ON

CONNECTOR AND CONTROLS ON THE DEVICE

FRONTAL PEN HOLDERS

USING THE REMOTE CONTROL

SETTING UP I3CONNECT STUDIO

I3CONNECT STUDIO LAUNCER HOME INTERFACE

GENERAL SAFETY PRECAUTIONS

Before taking this product into use, please read and understand his manual and its guidelines thoroughly.

Keep this manual for future reference and for training future additional operators of the product.

Placement and Ambient Conditions

- The allowable temperature range of the local ambient environment at which this
 device may operate is between 0°C and 40°C.
- Do not place the product near a radiator, heater, or other heat source.
- If the unit is suddenly moved from a cold to a warm place (e.g. from a truck), keep the
 power cable unplugged for at least 2 hours and make sure that any moisture inside the
 unit is evaporated.
- Do not expose the unit to rain, or a very humid weather condition.
- Make sure that the indoor environment is dry and cool. The allowable humidity range
 of the local ambient environment at which this device may operate is between 10% RH
 and 90% RH.
- Place the unit in a well-ventilated place, so heating can escape easily. Ensure that the
 unit has enough space for ventilation. A 10 cm space at the left, right, and bottom of
 the unit should be clear, and 20 cm should be kept clear above the device.

Environmental

 Do not dispose of batteries in the trash. Always follow local regulations on the collection of batteries.

Other

 All images and instructions within this manual are designed or written mainly for indicative purposes. There may be differences or changes between pictures/ instructions and the actual product.

GENERAL SAFETY PRECAUTIONS

Setup and Installation

- Read the complete installation guide, and prepare all tasks, before executing the first step.
- · Do not put heavy objects on top of the unit.
- Do not put the unit near appliances that generate magnetic fields.
- Do not expose the unit to direct sunlight and other sources of heat.
- Do not place the unit on an unstable cart, stand, tripod, bracket, table, or shelf.
- Do not put any liquid near or on the unit, make sure do not spill any liquid inside the unit.

Electrical Safety

- Keep the power cable risk-free from physical or mechanical damage.
- Check and ensure that the power source (wall outlet) is connected with the ground.
- Unplug the power supply to the unit when the weather is thunder-storm or lightning.
- Check that your local power supply characteristics are suitable for the product's operation voltage.
- Only use the original power cable from the accessory bag. Don't modify or lengthen it.
- Unplug power supply cable when the unit will be in inactive for a longer time.

Maintenance and Cleaning


- Always unplug the power cable before cleaning.
- Clean the screen only with soft, dustless, dry cloths, especifically intended for LCD screen cleaning.
- · For a deeper clean, always contact an authorized service center.
- Never use water or any spray-type detergent to clean the unit.
- Do not open the device. There are no user-serviceable parts inside.

UNBOXING

Two people are needed to do the unboxing and the consecutive installation of the display. Make sure to get your wall-mount or stand ready first before you unbox the display.

STEP 1

Remove the plastic clips on the 75" or the 86" boxes. The 65" does not have these clips.



STEP 2

Remove the straps. Lift up the cover and clear protective materials



STEP 3

Install any hardware needed to hang the dusplay (refer the the manual of the accessory)



STEP 4

Keep the packaging for future use.


HANDLING

The display is big and heavy. The 65" and 75" should be handled by two people.

To handle the 86" version of the display, 3 people are recommended.


i3CONNECT ASPEN 65" and 75"

Handle by two people



i3CONNECT ASPEN 86"

Handle by three people



WHAT ELSE IS INSIDE OF THE BOX?


Accessory box

- Power cable, length 3m.
 One end is a standardized IEC C13 (female plug) that inserts into the display.
 The other end is a localized socket plug. If you need a longer cable or a different socket plug, these can be sourced locally.
- Remote control unit
- Set of batteries for remote control unit.
- Ouick Start Guide
- 1x USB type C cable, 3m
- 1x HDMI cable, 3m
- 1x Touch cable, 3m

Set of display markers


 Two markers that are optimized for ease of use on the touch surface of the display. Settings of colour and width can be made through the i3CONNECT Studio operating system.

PRODUCT IDENTIFICATION



- A mounting bracket or cart is not included with your display, as there are various
 options to install the display to suit your requirements: fixed to the wall, height
 adjustable, mobile -or a combination of the above.
- Consult i3-CONNECT.com to see different options.
 Refer to the installation manual of the chosen mount.
- The display has standardized VESA mounting points at the back, using M8 size screws to install. Most of the mounts on the market are compatible to this standard. They vary in steps of 10 cm of width and height and also the maximal load they can accept. If adding accessories such as soundbars and/or camera systems, take this into account.
- Refer to the drawings in this chapter to find the specifications and position, different for each size.


Location of the VESA mount



i3CONNECT Aspen 4 65"

MODEL	VESA	POSITION OF UPPER MOUNTING POINT FROM TOP EDGE OF THE FRAME	WEIGHT WITHOUT ACCESSORIES
Aspen 4 65"	600 x 400	291 mm	38 kg


Location of the VESA mount



i3CONNECT Aspen 4 75"

MODEL	VESA	POSITION OF UPPER MOUNTING POINT FROM TOP EDGE OF THE FRAME	WEIGHT WITHOUT ACCESSORIES
Aspen 4 75"	800 x 400	213 mm	50 kg

Location of the VESA mount




i3CONNECT Aspen 4 86"

MODEL	VESA	POSITION OF UPPER MOUNTING POINT FROM TOP EDGE OF THE FRAME	WEIGHT WITHOUT ACCESSORIES
Aspen 4 86"	800 x 600	306 mm	66 kg

NETWORK CONNECTION

OPTION 1: LAN NETWORK

Plug in the LAN cable (if available) into one of the two LAN ports at the bottom of the display.



OPTION 2: WIFI NETWORK

Search for the required wireless network and key-in the matching password



FIRST TIME POWER ON

Turning the i3CONNECT display on and off

- Plug one side of the power cord into the AC power outlet and the other side into the wall socket.
- 2. Switch on the Power Switch to turn the i3CONNECT interactive display on.
- 3. The display is in standby mode now. Wait a moment until the power indicator lights up. Then press () button on the remote or the button on the display again, to turn the i3CONNECT interactive dispay on.
- 4. Press () button on the remote or the button on the display again, to turn the display in standby mode.
- 5. Switch off the Power Switch to cut off the power completely

Note: The i3CONNECT interactive display needs some time to shut off correctly before it can be switched on again. By interupting this process, the next start up can take longer.

Note: When there is no active source on the i3CONNECT display, it will go into stand-by mode after 3 minutes.

Connections

Make sure both the external device as well as the i3CONNECT display are turned off when connecting the external device to the display.

Check the plugs at the ends of the cables to make sure that they are the correct type, before plugging them into the jacks of the i3CONNECT interactive display.

FIRST TIME INSTALLATION

When turning on the i3CONNECT display for the first time, the following menu pages appear on the screen.



Hi there!



When your device is not connected to LAN already, select your wireless network



Select your date & time preferences



Set your Google Services





Set a PIN to increase security



Applying the settings so please wait


Connections on the front of the display






NR.	CONNECTIONS
1	Remote Control Sensor
2	Ambient Light Sensor
3	Motion Sensor


Connections on the left side of the display



NR.	CONNECTION
1	OPS Module Slot
2	2x USB-A 3.0
3	USB-C Out
4	Touch Out 3
5	HDMI 3
6	DisplayPort In
7	HDMI-Out
8	HDMI 2
9	HDMI 1
10	Touch Out 2
11	USB-C 1
12	Power button
13	Multi function button
14	USB-C Side

Connections on the bottom and top of the display





NR.	BOTTOM CONNECTIONS
1	Touch Out 1
2	RS232-C Male
3	SPDIF (TOSLINK)
4	USB-A 2.0
5	VGA
6	Audio-in (3.5mm jack)
7	LAN 1 & 2
8	Headphone out (3.5mm jack)
NR.	TOP CONNECTIONS
9	Connector for optional accessory

Different connections and their descriptions

CONNECTION	DESCRIPTION	
Video out: HDMI & USB C	Connect an external device with a HDMI cable or USB-C cable to this port to output the image and sound of the interactive display.	
USB 3.0	Connect a USB device to this port for OPS or Android.	
	Connect an external device with an USB-C Cable to this port.	
USB-C	NOTE: the display supports USB 3.2 Gen 1x1. This supports built-in Touch Out.	
Display port (DP) In	Connect an external device with a DP cable to this port.	
HDMI In	Connect an external device with a HDMI cable to this port.	
Touch out	Connect an external device to support touch control of an external device on the display.	
	NOTE: Windows is Plug&Play, for Apple gestures a driver is needed.	
Wi-Fi and Bluetooth antennas	Tighten to Wi-Fi and Bluetooth antennas in clockwise direction.	
USB 2.0	Connect a USB device to this port for Android.	
PC in	Connect an external device with VGA cable and Mini Jack to this port.	
S/PDIF output	Connect a digital sound system to this SPDIF jack.	
Headphone out	Connect a headphone to this jack.	
LAN	Connect an external network/router with a LAN cable to this port.	
RS-232C	Connect a DB-9 cable to this port for remote control, service and other uses.	
Analogue Audio in	Connect an external analogue audio device with a Mini Jack cable to this jack.	

CONNECTION	DISCLAIMER
HIGH DEFINITION MULTIMEDIA INTERFACE	The term HDMI and HDMI High-Definition Multimedia INterface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc. In the United States and other countries.
USB	USB4®, USB Type-C® and USB-C® are registered trademarks of USB Implementers Forum. USB 2.0 Type-C™ is a trademark of USB Implementers Forum

FRONTAL PEN HOLDERS


The bottom bezel of the display has two recessed areas that magnetically hold a matching stylus.





REMOTE CONTROL

Button allocation of the remote cotrol



REMOTE CONTROL

Install the supplied batteries to get the remote working. Replace the batteries when the remote starts becoming less responsive or stops working.

NOTE: remove the batteries when you are planning to not use the remote for over a month.



2x AAA batteries Pay attention to the correct orientation.

If you ever need to replace them, use Alkaline or rechargable types only.

Push down the cover of the battery compartment and slide it off to get access







SETTING UP i3CONNECT STUDIO

About i3CONNECT Studio

i3CONNECT Studio is the intuitive interface that lets you explore all possibilities of this device and manage all settings. Refer to the online manual of i3CONNECT Studio to get all the relevant information.



Setting up i3CONNECT STUDIO



Making sure you get the latest and greatest



Optionally activate Google EDLA



Choose the best setup for your needs

SETTING UP i3CONNECT STUDIO

About i3CONNECT Studio


i3CONNECT Studio is the intuitive interface that lets you explore all possibilities of this device and manage all settings. Refer to the online manual of i3CONNECT Studio to get all the relevant information.




Type a unique but recognizable device name



Register your display to make use of remote management



Check out the terms of use



You're all set!

STUDIO LAUNCHER HOME INTERFACE



 Clock and date widget: time flies when you're having fun, so we help you to not lose track of time

2. Status bar:

- **A: i3CAIR air** quality widget (needs optional i3CAIR sensor to monitor the air quality of the room that you are in)
- **B: Display name** (the assigned name you set in one of the previous steps)
- **C: WIFI status** (name of connected network)
- **D: i3CONNECT ALLSYNC key** (to wirelessly connect your device)
- 3. Side bar menu (access tools, setting, warnings)
- 4. Side bar menu controls (show and hide the Side bar menu)
- **5. Widget tiles:** (Add and lauch favorite applications with one touch. Initial widgets may vary upon the chosen preset 'Educational' or 'Business')
 - **A:** Write (Use the display as a flipchart or whiteboard)
 - **B:** Present (Share content from your device and use the display to control it)
 - **C: Browser** (Browse the internet, annotate and share the information)
 - **D: USB-C** (Select the frontal input for wired connection)
- 6. Exit (and go to...)

END OF LIFE

We are extending the lifespan of our products with modular technologies and we're even able to give our products a second life after first use. We're proud of what we're doing for a more sustainable world.

We're committed to increase the circularity of our products and improve the recyclability and re-use at the end-of-life to prevent any unnecessary waste.

Comes that time that you must part with one of our products, please consult our website to get the newestinstructions how to proceed.

We are the first (and currently only) touchscreen manufacturer with a <u>circular passport for our touchscreens</u>. This includes a transparent overview in the materials we use, the CO2-impact of our solutions, as well as a showcase of initiatives we take to minimize our impact.

Recyclability of our products

At a product's end-of-life, valuable materials often end up being disregarded and dumped in landfills. We believe that sustainability doesn't end when our products have reached the end of their usable life. That's why we've conducted a study to investigate the recyclability of our products.

The results?

- 88% of the materials used in our products can be recycled.
- 12% is incinerated with energy recovery.
- A fraction of 0,1% ends up in regulated landfills.

We're committed to increase the circularity of our products and improve the recyclability and re-use at the end-of-life to prevent any unnecessary waste.

